

DBX 1531X PARTS LIST

PART NO#	DESCRIPTION	COST
90-0052	TRANSFORMER/POWER 1531X DOM.	9.24
36-0068	POWER/CORD 1531X DOM.	4.92
90-0070	FRONT PANEL(SCREENED)	18.96
90-0067	REAR PANEL(SCREENED)	9.48
90-0306	XLR/MALE 1531X	2.68
90-0304	XLR/FEMALE 1531X	3.40
90-0301	1/4" JACK 1531X	1.44
90-0334	POT/SLIDER 100K, 1531X	3.24
90-0009	BUTTON CAP FOR SLIDER BLACK/WHITE P	.36
90-0311	CABLE/HARN. CODE 12345/67890	2.52
90-0316	SWITCH ASSY.FOR(20HZ,60HZ,120HZ)	7.32
90-0317	SWITCH ASSY.FOR(RANGE,H PASS,BYPASS)	8.52
90-0026	SWITCH ADAP.FOR(20HZ,60HZ,120HZ)	.44
90-0027	SWITCH ADAP.FOR(RANGE,H.PASS,BYPASS)	.36
90-0028	SWITCH ADAP.FOR(POWER)	.32
90-0319	SWITCH/POWER 1531X	7.28
90-0012	BUTTON CAP/POWER	.36
90-0007	BUTTON CAP(RANGE,H.PASS,BYPASS, 20HZ,60HZ,120HZ)	.36
90-0318	SWITCH/STEREO,MONO	.76
32-3137	RIBBON(MAIN TO FRONT/MAIN TO REAR)	6.00
90-0056	RACKEAR 1531X	2.52
18-2032	OWNER'S MANUAL 1531X	3.04
18-2047	SERVICE MANUAL 1531X	13.68